

1. Connect battery cable (red and black cable) with solar panel controller (red + and black -) and tighten it.
2. Connect short black solar panel cable with solar panel controller – black cable with blue and brown wire. Brown wire to + and blue wire to – and tighten it.
3. Connect black cable for connecting the gateway and solar panel controller – black cable with round pin connector. Black cable with white lines to + and fully black cable with no lines to – and tighten them.
4. Mount the solar panel on a secure and sunlight exposed spot (i.e. apiary roof).
5. Connect the battery cable to the battery (red + and black -).
6. Connect the black cable from the solar panel to the short solar panel cable that you connected to the solar panel controller and tighten it.
7. Plug the black cable with round pin to the gateway.

\*When uninstalling the solar panel please always disconnect the solar panel cable first, then the battery and at the end the gateway.

